

Learning procedure:

- 1) Simultaneously press keys A and B on the Jolly Open until the LED flashes continuously; release the keys.
- 2) Simultaneously press the key to be duplicated on the original remote control and the key to be programmed on the Jolly Open; the LED will begin to flash continuously; release the keys.
- 3) Repeat this process to program all other keys on the Jolly Open.
- 4) Simultaneously press keys C and D on the Jolly Open until the LED flashes continuously; release the keys.

Note: Any keys not reprogrammed will remain programmed as they were before the procedure indicated above.

**Procedura di apprendimento:**

- 1) Premere contemporaneamente i tasti A e B sul Jolly Open fino a che il led non inizi a lampeggiare in modo costante; rilasciare i tasti.
- 2) Premere il tasto sul radiocomando da duplicare e contemporaneamente il tasto da programmare sul Jolly Open fino a che il led non inizi a lampeggiare in modo costante; rilasciare i tasti.
- 3) Ripetere il punto 2 per programmare anche i rimanenti tre tasti programmabili del Jolly Open.
- 4) Premere contemporaneamente i tasti C e D sul Jolly Open fino a che il led non inizi a lampeggiare in modo costante per confermare la programmazione; rilasciare i tasti.

NB: tutti i tasti non programmati di nuovo rimarranno programmati come prima di effettuare la procedura sopra elencata.

