

LT LED 120W SPOT - DMX protocol



MODE			DMX VALUE		FUNCTION	CONTROL	DEFAULT VALUE
9 CH	11 CH	14 CH					
1	1	1			Pan		128
			0	255	Pan 0° - 540°	Fade	
-	-	2			Pan fine		128
			0	255	Pan fine	Fade	
2	2	3			Tilt		128
			0	255	Tilt 0° - 270°	Fade	
-	-	4			Tilt fine		128
			0	255	Tilt fine	Fade	
-	-	5			Pan/Tilt speed		0
			0	255	Speed (fast → slow)	Fade	
3	3	6			Dimmer		0
			0	255	0 ~ 100 % (dark → bright)	Fade	
4	4	7			Strobe		0
			0	7	Strobe off	Step	
			8	250	Strobe (slow → fast)	Fade	
			251	255	Strobe off	Step	
5	5	8			Colour wheel		0
			0	15	White	Step	
			16	31	Red	Step	
			32	47	Green	Step	
			48	63	Yellow	Step	
			64	79	Blue	Step	
			80	95	Magenta	Step	
			96	111	Orange	Step	
			112	127	Cyan	Step	
			128	191	Forwards rainbow effect (slow → fast)	Fade	
192	255	Backwards rainbow effect (slow → fast)	Fade				
6	6	9			Gobo wheel		0
			0	7	Open	Step	
					Positioning		
			8	15	Gobo 1	Step	
			16	23	Gobo 2	Step	
			24	31	Gobo 3	Step	
			32	39	Gobo 4	Step	
			40	47	Gobo 5	Step	
			48	55	Gobo 6	Step	
			56	63	Gobo 7	Step	
					Shaking gobos (slow → fast)		
			64	71	Gobo 7	Fade	
			72	79	Gobo 6	Fade	
			80	87	Gobo 5	Fade	
			88	95	Gobo 4	Fade	
			96	103	Gobo 3	Fade	
104	111	Gobo 2	Fade				
112	119	Gobo 1	Fade				
120	127	Open	Step				

LT LED 120W SPOT - DMX protocol



6	6	9			Wheel rotation		0
			128	191	Forwards gobo wheel (slow → fast)	Fade	
			192	255	Backwards gobo wheel (slow → fast)	Fade	
7	7	10			Focus		128
			0	255	Continuous adjustment (far → near)	Fade	
8	8	11			Prism		0
			0	63	Open	Step	
			64	255	3-facet circular rotating prism	Step	
9	9	12			Prism rotation		0
			0	15	Stop	Step	
			16	135	Forwards prism rotation (slow → fast)	Fade	
			136	255	Backwards prism rotation (slow → fast)	Fade	
-	10	13			Macro		0
			0	15	No macro	Step	
			16	45	Macro 1	Step	
			46	75	Macro 2	Step	
			76	105	Macro 3	Step	
			106	135	Macro 4	Step	
			136	165	Macro 5	Step	
			166	195	Macro 6	Step	
196	255	Macro 7	Step				
-	11	14			Reset		0
			0	249	No function	Step	
			250	255	System reset	Step	